




Kit 1390

NISSAN Serena, 5-dr MPV, 05-09


SUZUKI Landy, 5-dr MPV, 07-09



754 Rapid System
480R Rapid Traverse (North America)



480 Traverse (North America)



The diagram illustrates the importance of instructions. It features a box on the left labeled 'THULE' with a warning symbol (a triangle with an exclamation mark) and a plus sign next to it. To the right of the plus sign is a box labeled 'instructions' with a warning symbol and the text 'Kit XXXX'. A person is shown reading the instructions.

754 Rapid System **x1**










480R Rapid Traverse (North America) **x1**

754 Rapid System **x4**

480R Rapid Traverse (North America) **x4**

754 Rapid System **x4**


480R Rapid Traverse (North America) **x4**





758	x 4
-----	-----




220	x 4
-----	-----


RR	FR
	
FL	RL
	

x 1



1





2





754 Rapid System
480R Rapid Traverse
(North America)



x4





x4



x4




480 Traverse
(North America)




x4

3



754 Rapid System




X

NISSAN Serena, 5-dr MPV, 05-09

42,5

SUZUKI Landy, 5-dr MPV, 07-09

42,5



Y

NISSAN Serena, 5-dr MPV, 05-09

41,5

SUZUKI Landy, 5-dr MPV, 07-09

41,5

3




480R Rapid Traverse



480 Traverse



(North America)



X inch

X mm

NISSAN Serena, 5-dr MPV, 05-09


42 ³/₈ "

1076 mm

SUZUKI Landy, 5-dr MPV, 07-09

42 ³/₈ "

1076 mm



Y inch

Y mm

NISSAN Serena, 5-dr MPV, 05-09

42"


1066 mm

SUZUKI Landy, 5-dr MPV, 07-09

42"



1066 mm

4





5



NISSAN Serena, 5-dr MPV, 05-09
SUZUKI Landy, 5-dr MPV, 07-09




6



	X mm	Y mm	X inch	Y inch
NISSAN Serena, 5-dr MPV, 05-09	835 mm	635 mm	32 ⁷ / ₈ "	25 "
SUZUKI Landy, 5-dr MPV, 07-09	835 mm	635 mm	32 ⁷ / ₈ "	25 "







7





GB/US Tighten alternately
D Die Schrauben abwechselnd anziehen
F Serrer alternativement chaque côté
NL Afwisselend aan de linker- en de rechterkant aandraaien
I Alternare il serraggio delle viti
E Apretar alternativamente
PT Aperte alternadamente
S Dra åt växelvis
FIN Kierrä vuorotellen
EST Pinguldage vaheldumisi
LAT Pieļieciet pamišus
LIT Užsukinėkite pakaitomis
PL Śruby dokręcaj naprzemiennie
RU Затягивайте попеременно

CZ Pokręťta багаžníka dokręcaj dokręcaj naprzemiennie.
SK Dofahujte striedavo
SLO Privijajte izmenično.
HR Naizmjenično zategnite
HU Egymástól fűggetlenül szorítandó
GR Σφιγγετε εναλλάξ
TR Dönüşümlü sıkın

中文 交替拧紧
한국어 번갈아 가며 조이십시오.
日本語 交互に締め付けてください。
ไทย ชั้้นในแบบสลับ





≈ 3 Nm





8



x1
17 mm





THULE
SWEDEN

**ONE
KEY
SYSTEM**

544 (x4)

596 (x6)

588 (x8)

NA **510** (x10)

EUR **452** (x12)

ASIA